

Internet Connection Setup

Curriculum Mode saves student scores to the **Performance Portal** if your SimSpray is connected to the internet. **Do this as part of your initial SimSpray setup.**

This applies to units running software v3.3 or later.

Note: if not allowed to connect SimSpray to the internet, contact support@vrsim.net for offline Curriculum Mode instructions instead.

Setup Steps:



To access your keyboard and mouse, first unscrew the two thumb screws from the backplate.




Remove the backplate.







Open the keyboard and mouse box, and take the keyboard and mouse out.



Connect the keyboard and mouse USB connections to the front USB ports on the unit.








Press the power button at the front of the unit to turn SimSpray on. After the software loads, hit the Windows key to open the taskbar.



Once the taskbar is open, find the internet connection icon and click on it.




Find your local wifi connection, ensure the "connect automatically" box is checked, and then connect to that wifi connection. Enter your wifi credentials if prompted. You do not need the computer to be discoverable. This should be all you need to do to ensure that your unit automatically connects to your wifi when you start it up.


Note: if the wifi connection is weak or not stable, you may need to add compatible wifi antennas to the computer or use a wired ethernet connection instead. Contact support@vrsim.net for specifications.







Press the Windows key to open the taskbar.



Type "Chrome" using the keyboard, and hit enter to run Google Chrome.



In Chrome, in the navigation bar at top, type the following, and then press Enter: https://portal.simspray.net



Verify the page loads. If not, then diagnose your internet connection or ask your IT team to whitelist that site.




Exit out of Chrome.






Windows Update Settings:



Tap the Windows key, search for, and select Check for Updates.



If you want to change active hours, select "Change active hours", and make any adjustments.

Note: you may also want to change your Windows system date, time, and timezone.





Exit out of the Updates window.

Clean Up:



Clean up by disconnecting the keyboard and mouse from the unit, placing them back in the box on the back plate, securing the back plate, and screwing back in the two thumbscrews to the backplate.

