## SimSpray 3.x Tech Specs

Category		Description						
Weight		Unit Only:	145 lbs (w/o blaster) 158 lbs (w/ blaster)			66 kg (w/o blaster) 72 kg (w/ blaster)		
		Pallet Pack Container:				97 kg (w/o blaster) 104 kg (w/ blaster)		
Dimensions (W x D x H)		In Use:	51"x 25" x 81"			1.2954 x 0.635 x 2.0574 m		
		Closed:	24.5" x 25.25" x 48"			0.6223 x 0.6414 x 1.2192 m		
		Pallet Pack Container:	31" x 53" x 30"			0.7874 x 1.3462 x 0.762 m		
Working Space (Zone) Dimensions (W x D x H)		Ideal Open Space:	Minimum: 10' x 11' x 10'			Minimum: 3.048 x 3.3528 x 3.048 m		
			1 '			6.7' x 6.7'	2.0422 x 2.0422 m	
			select trackable zones from default room snapes		М	12.5' x 15.7'	3.81 x 4.7854 m	
					L	12.5' x 25'	3.81 x 7.62 m	
		See the Positioning section of the Quick Start Guide. Minimize reflections or infrared interference. SimSpray uses a camera based tracking system. Cover sources of IR (Infrared) interference, turn off infrared emitting devices, or reposition or move the system.						
Power Requirements		Input Voltage	Input Frequency	Current		Misc.		
	US	120 VAC	2-5 Amps			Standard, 3-pronged, bladed, household outlet		
	INTL	100-250 VAC	50-60Hz	(In-Use: 2 Amps, Max: 5 Amps)		Regional power plug adapter included		
SimSpray Peripherals		VRSim Spray Gun, Powder Gun, and/or Abrasive Blasting Gun (infrared motion tracked) (supports 1 active user at a time)						
		VIVE Pro (infrared motion tracked first-person perspective video) (2880 x 1600 resolution, 90 Hz, 110° field of view)						
		Touchscreen (touch interface and video) (1080p, 1920x1080 resolution, 60 Hz)						
		Speakers (sound)						
i o i				res an internet connection (wired preferred, WiFi available). If no internet filine mode, but users will not be able to use the Performance Portal.				
Optional External Device Connections		HDMI AV to an additional external display (TV or Projector). SimSpray outputs 1080p (widescreen 1920x1080 resolution, progressive mode) at 60 Hz. Additional external display and cabling not included but recommended if showing to 4+ people at the same time.						
		USB flash drive. Instructor USB included to collect SimSpray reports. Optionally, students and trainees may want their own USBs, not included. System supports 1 USB inserted at a time. Use a non-SimSpray computer to distribute (email), print, make copies of, and/or delete reports.						
Tech Support Needs		Wired internet connection preferred, WiFi secondary. Requires connecting the included Computer and Mouse. Ethernet cabling not included. Online connection recommended (starting in v3.3 and to support Curriculum Mode). Software updates and tech support may require an additional USB and non-SimSpray computer with internet access and access to download files (e.g., Dropbox).						

Note: See Computer Tech Specs in a separate file. All specs are subject to change and may be replaced with comparable hardware or system.